

ANALYST:		VPDES NO	
----------	--	----------	--

Parameter: Total Residual Chlorine
Method: Titrimetric, Iodometric Back (Iodate Titrant)
04/01

METHOD OF ANALYSIS:

	18th EDITION OF STANDARD METHODS-4500-CL C
--	--

	Y	N
1) Is PAO or sodium thiosulfate normality 0.00564N? [SM-3.c]		
2) Is a blank determined daily? [SM-4.b.3]		
3) Is the blank titration documented? [Permit]		
4) Is iodate normality 0.00564N? [SM-3.j]		
5) Are reagents free of contamination or growths? [Permit]		
6) Are reagents within their indicated shelf lives? [Permit]		
7) Is 200 mL of sample used? [SM-4.a.1]		
8) Is 5 mL of PAO or thiosulfate used? [SM-4.a.2]		
9) Is KI added? [SM-4.b.3]		
10) Is 2 mL 10% H ₃ PO ₄ added? [SM-4.b.3]		
11) Is at least 1 mL starch solution added? [SM-4.b.3]		
12) Are the reagents added in order-e.g. PAO or thiosulfate first, KI second, 10% H ₃ PO ₄ third, and starch solution fourth? [SM-4.b.3]		
13) Is the sample titrated immediately after sample solution is mixed? [SM-4.b.3]		
14) Is the titrant added until the first appearance of blue color that persists after complete mixing? [SM-4.b.3]		
15) Is the sample value calculated correctly? [SM-5.b]		
$\text{TRC (mg/L)} = \frac{(A - B) \times 200}{C}$ <p>A = mL iodate used for blank B = mL iodate used for sample C = mL of sample</p>		

PROBLEMS: